DEPARTURE ROUTE DESCRIPTION

TAKE-OFF RWY 23: Climb straight ahead to 848 (500 QFE), thence...

CLN 8R: Straight ahead to I-SX 1 DME (BKY VOR/DME R-149), then turn left to intercept the CLN VOR/DME R-269 by XIGAR (CLN 33 DME) to CLN VOR/DME. Cross CLN 28 DME at or above 3000. Cross CLN 21 DME at 4000. Cross CLN 16 DME at 5000. Cross CLN 13 DME at 6000. At speeds below 195 KIAS do not turn East of track 140°. Intercept CLN VOR R-269 by CLN 33 DME (XIGAR).

TAKE OFF RWY 05: Climb straight ahead to 848 (500 QFE), thence...

CLN 4S: Straight ahead to I-SED 1 DME (BKY VOR/DME R-123), then turn right onto BKY VOR/DME R-118 to intercept CLN VOR/DME R-269 to CLN VOR/DME. Cross BKY 14 DME at or above 2500. Cross BKY 17 DME at or above 3000. Cross CLN 21 DME at 4000. Cross CLN 16 DME at 5000. Cross CLN 13 DME at 6000.