T

DEPARTURE ROUTE DESCRIPTION

TAKE-OFF RWY 13: Cross departure end at least 13 AGL/560 MSL. Track heading 132° until EIL 6 DME. Cross EIL R-132/6DME at or above 4000. Turn right to intercept the EIL R-183 and proceed inbound to EIL. Cross EIL at or above 5000. Intercept and proceed outbound on EIL R-332. Cross EIL R-332/17 DME at or above 10,000, thence...

TAKE-OFF RWY 31: Cross departure end at least 17 AGL/550 MSL. Turn right to intercept and track outbound on EIL R-332. Cross FRITZ (EIL R-332/10 DME) at or above 5000. Cross EIL R-332/17 DME at or above 10,000, thence...

AXSEM GATE TRANSITION: Turn right and track outbound on FAI R-041. Cross AXSEM (FAI R-041/35 DME) at 14,000 block 16,000.

APPEL GATE TRANSITION: Cross EIL R-332/24 DME at or above 14,000. Turn right and track outbound FAI R-027. Cross FAI R-027/45 DME at or above FL180. Cross APPEL (FAI) R- 027/62 DME) at FL 220 block FL 260.

CABIN GATE TRANSITION: Cross EIL R-332/24 DME at or above 14,000. Cross EIL R-332 /31 DME at 16,000 block FL 200. Turn right and track outbound on FAI R-017. Cross FAI R-017/40 DME at FL 200. Cross FAI R-017/55 DME at or above FL 220. Cross CABIN (FAI R-017/87 DME) at FL 220 block FL 260.